

# LOADING INSTRUCTIONS

## PATENTED 40MM CANNON BASE



1. Load and Press the small 1 ½ pistol primer

Use a drill press or press with perfectly flat metal stock to insert primer



2. Measure your smokeless powder (We recommend Bulls-Eye)



3. Pour powder charge into stainless High Pressure Chamber



4. Install copper burst disk (sharp edge up) covering powder charge and resting on High Pressure Chamber ledge



5. Install stainless vent plug and snug up with 15mm wrench



**Charging base is loaded and dangerous. Handle with care.**



### Payload

6. Push wad in until flush. Cut wad pedals if still connected. Pour payload of buckshot or fletchettes



7. Install cardboard or foam disk to secure payload pushing wad into bottom of tube



8. Install payload filled tube. Casing is now charged and ready.

Follow All Safety Guidelines. Pace Launchers LLC is not responsible for any damage, injury, and/or death that results in loading and/or improper loading of these casings and/or any other device. Make sure to follow all local and federal laws.